



TRANSPORT INSTRUCTIONS FOR CYLINDER LINER

There should be 7 cm of protection around the entire cylinder liner with a cushioning material such as bubble wrap.

- 7 cm with bubble wrap at the bottom.
- 7 cm with bubble wrap on each side.
- 7 cm with bubble wrap on the top.
- Packed standing in pallets or individually in cardboard box.

